Accordion Midi Setup

Set Up Midi In Sd40
- Press Menu
- Touch Midi According Style Voice On
- Touch Arranger Keyboard
- Touch Rx (Midi Receive) on
- Set Right, Left, Bass
  If Using Keyboard Midi Controller
  Then Set Only "Global"

See Manual For Midi Accordion Set Up

Midi Out

Right / Lead Out
Channel 1

Left / Chords Out
Channel 3

Bass Out
Channel 2

Midi Cable!!!

Right / Lead In
Channel 1

Left / Chords In
Channel 3

Bass In
Channel 2

Midi In (2)